

Infiniti G35 Voice Recognition Cheat Sheet

Help

Help	Displays the command list.
Music Box	
Music Box Play	Turns on the "Music Box" hard-disk drive audio system.
Play by Mood	Plays the specified song matching your mood.
Relaxing Music	Plays the specified relaxing music.
Lively Music	Plays the specified lively music.
Slow Music	Plays the specified slow music.
Upbeat Music	Plays the specified upbeat music.
Play by Category	Plays the specified song in the specified Category.
My Favorites	Plays your favorite song.
Rarely Played	Plays a rarely played song.
Hit Songs	Plays the specified hit song.
Kid's Songs	Plays the specified songs for children.
Music Box Off	Turn the "Music Box" off.

Radio

Radio Play	Turn the radio on, selecting the station and band last played.
Radio AM	Turns to the AM band, selecting the station last played.
Radio FM	Turns to the FM band, selecting the station last played.
Tune <87.7 - 107.9>	Tunes to the specified FM frequency.
Tune <530 - 1710>	Tunes to the specified AM frequency.
Preset <A - C> <1 - 6>	Switches directly to the specified preset station in the specified preset bank.
Preset <A - C>	Switches directly to the specified preset station in the specified preset bank.
Preset <1 - 6>	Switches directly to the specified preset bank.
Radio Off	Turns the radio off.
Radio Menu	Displays the radio menu.

Satellite

Satellite Radio	Turns the SAT radio on selecting the station and band last played.
Satellite Radio Chanel <1-255>	Tunes to the specified SAT frequency.
Preset <A - C> <1 - 6>	Switches directly to the specified preset station in the specified preset bank.
Preset <A - C>	Switches directly to the specified preset station in the specified preset bank.
Preset <1 - 6>	Switches directly to the specified preset bank.
Radio Off	Turns the radio off.
Radio Menu	Displays the radio menu.

CD

CD Play	Starts to play a CD.
Track <1 - 512>	Switches to the specified track.
Folder <1 - 255>	Selects the specified MP3 folder and plays the first file.
Folder <1 - 255> Track <1 - 512>	Switches to the specified track on the specified MP3 folder.
CD Off	Stops the CD playback.
CD Text	Displays the information about the track currently being played.
CD Menu	Displays the CD Menu.

CD Changer

CD Changer Play	Starts to play the CD Changer.
Disk <1 - 6>	Switches to the specified CD and plays the first file.
Track <1 - 99>	Switches to the specified track.
Disk <1 - 6> Track <1 - 99>	Switches to the specified track in the specified CD.
CD Off	Stops the CD playback.
CD Menu	Displays the CD Menu.

Audio

Audio Play	Turns the audio system on.
Audio Off	Turns the audio system off.

CF

Compact Flash Play	Starts to play the files saved in the CompactFlash card.
Track <1 - 512>	Switches to the specified track.
Folder <1 - 255>	Selects the specified folder in the CompactFlash card and plays the first file.
Folder <1 - 255> Track <1 - 512>	Switches to the specified track in the specified folder in the CompactFlash card.
Compact Flash Off	Stops the playback of the CompactFlash card.
Compact Flash Text	Displays the information about the file currently being played.
Compact Flash Menu	Displays the CompactFlash Menu.

Vehicle

Fuel Economy	Displays the Fuel Economy screen.
Maintenance	Displays the Maintenance screen.
Status	Displays the Status screen.

Infiniti G35 Voice Recognition Cheat Sheet	
Phone	
Phone Redial	Redials the phone number last dialed.
Phone Dial	Dials the phone number given in the command.
Phone Dial < Phone Number>	Dials the phone number given in the command.
Phonebook	Shows the first page of the "Phonebook" list.
Phonebook <Voicetag>	Dials the phone number registered in the specified "voicetag".
Outgoing Calls	Shows the outgoing call history (1 to 5).
Incoming Calls	Shows the incoming call history (1 to 5).
Phone Select	Selects another cellular phone registered in system.
Play Phonebook	Outputs the "Voicetags" registered in the system.
Climate Control	
Climate Control	Turns the climate control system on and operates it in AUTO mode.
Climate Control Off	Turns the climate control system off.
Temperature <60 - 90>	Sets the climate control temperature to the specified value.
Driver Temperature <60 - 90>	Sets the driver's side temperature to the specified value.
Passenger Temperature <60 - 90>	Sets the passenger's side temperature to the specified value.
Destination	
Destination Home	Sets a route to your home that is stored in the Address Book
Destination Address Book	Sets a route to a location stored in the Address Book.
Destination <Voicetag>	Sets a route to a stored location that has the voicetag specified.
Destination Nearby <POI Category>	Sets a route to the POI category near the current vehicle location.
Destination Nearby Places	Sets a route to a facility near the current vehicle location
Destination Previous Destinations	Sets a route to a previous destination.
Destination Previous Start Point	Sets a route to a previous start point.
Search	
Destination Street Address	Searches for a location by the street address specified and sets a route.
Destination Street Address <State>	Searches for a destination in the state specified and sets a route.
Destination Street Address Last State	Searches for a destination in the state previously specified and sets route.
Destination Street Address Last City	Searches for a destination in the city previously specified and sets route.
Destination Phone Number	Searches for a destination by the phone number specified and sets route.
Show Nearby <POI Category>	Searches for a POI near the current vehicle location and sets route.
Map	
Show Current Location	Displays the current location map screen.
Landmark Icons	Displays all the landmark icons.
Landmark Icons <POI Category>	Displays the landmark icons of the specified POIs.
Plainview Map	Displays the map in Plan View.
Birdview Map	Displays the map in Birdview.
Planview Split Map	Displays the map in Split (Plain View).
Birdview Split Map	Displays the map in Split (Birdview).
North Up	Sets the orientation of the map to North Up.
Heading Up	Sets the orientation of the map to Heading Up.
Zoom In	Zooms the map in.
Zoom Out	Zooms the map out.
<1, 2, 5, 8, 32, 400> Mile Scale	Displays the map in the specified scale (1, 2, 5, 8, 32, 400 miles).
<1/8, 1/4, 1/2> Mile Scale	Displays the map in the specified scale (1/8, 1/4, 1/2 mile).
<150, 300> Feet Scale	Displays the map in the specified scale (150, 300 feet).
<75, 150> Feet Building Scale	Displays the map in the specified scale (75 or 150 feet).
Route	
Fastest Route	Sets the route search condition to Fastest Route.
Minimize Freeway	Sets the route search condition to Minimized freeway.
Shortest Route	Sets the route search condition to Shortest Route.
Cancel Route	Cancel the route setting.
Detour	Calculates a detour.
Route Information	Displays the route information.
Recalculate	Recalculates a route.
Other Commands	
Traffic Info.	Turns on/off the traffic information system.
Guidance Voice	Turns on voice guidance.
Store Location	Stores a current location.
Guidance Voice Repeat	Repeats voice guidance once.
Play Address Book	Speaks voicetags stored in the Address Book.