



2007 INFINITI G35 Voice Recognition Cheat Sheet

AUDIO

Audio

Audio Play	Turns audio system on.
Audio OFF	Turns audio system off.

CD

CD Play	Starts to play a CD.
Track <1 - 512>	Switches to specified track.
Folder <1 - 255>	Selects specified MP3 folder and plays first file.
Folder <1 - 255> Track <1 - 512>	Switches to specified track on specified MP3 folder.
CD OFF	Stops CD playback.
CD Text	Displays information about track currently being played.
CD Menu	Displays CD Menu.

CD Changer

CD Changer Play	Starts to play CD Changer.
Disk <1 - 6>	Switches to specified CD and plays first file.
Track <1 - 99>	Switches to specified track.
Disk <1 - 6> Track <1 - 99>	Switches to specified track in specified CD.
CD OFF	Stops CD playback.
CD Menu	Displays CD Menu.

Compact Flash

Compact Flash Play	Starts to play files saved in CompactFlash card.
Track <1 - 512>	Switches to specified track.
Folder <1 - 255>	Selects specified folder in CompactFlash card and plays first file.
Folder <1 - 255> Track <1 - 512>	Switches to specified track in specified folder in CompactFlash card.
Compact Flash OFF	Stops playback of CompactFlash card.
Compact Flash Text	Displays information about file currently being played.
Compact Flash Menu	Displays CompactFlash menu.

Music Box

Music Box Play	Turns on "Music Box" hard-disk drive audio system.
Play by Mood	Plays specified song matching your mood.
Relaxing Music	Plays specified relaxing music.
Lively Music	Plays specified lively music.
Slow Music	Plays specified slow music.
Upbeat Music	Plays specified upbeat music.
Play by Category	Plays specified song in specified Category.
My Favorites	Plays your favorite song.
Rarely Played	Plays a rarely played song.
Hit Songs	Plays specified hit song.
Kid's Songs	Plays specified songs for children.
Music Box Off	Turn "Music Box" off.

Radio

Radio Play	Turn radio on, selecting station and band last played.
Radio AM	Turns to AM band, selecting station last played.
Radio FM	Turns to FM band, selecting station last played.
Tune <87.7 - 107.9>	Tunes to specified FM frequency.
Tune <530 - 1710>	Tunes to specified AM frequency.
Preset <A - C> <1 - 6>	Switches directly to specified preset station in specified preset bank.
Preset <A - C>	Switches directly to specified preset station in specified preset bank.
Preset <1 - 6>	Switches directly to specified preset bank.
Radio OFF	Turns radio off.
Radio Menu	Displays radio menu.

XM Radio

Satellite Radio	Turns SAT radio on selecting station and band last played.
Satellite Radio Channel <1-255>	Tunes to specified SAT frequency.
Preset <A - C> <1 - 6>	Switches directly to specified preset station in specified preset bank.
Preset <A - C>	Switches directly to specified preset station in specified preset bank.
Preset <1 - 6>	Switches directly to specified preset bank.
Radio OFF	Turns radio off.
Radio Menu	Displays radio menu.

NAV - Destination

Destination Home	Sets a route to your home that is stored in Address Book.
Destination Address Book	Sets a route to a location stored in Address Book.
Destination <Voicetag>	Sets a route to a stored location that has voicetag specified.
Destination Nearby <POI Category>	Sets a route to POI category near current vehicle location.
Destination Nearby Places	Sets a route to a facility near current vehicle location.
Destination Previous Destinations	Sets a route to a previous destination.
Destination Previous Start Point	Sets a route to a previous start point.
Destination Street Address	Searches for a location by street address specified and sets a route.
Destination Street Address <State>	Searches for a destination in state specified and sets a route.
Destination Street Address Last State	Searches for a destination in state previously specified and sets route.
Destination Street Address Last City	Searches for a destination in city previously specified and sets route.
Destination Phone Number	Searches for a destination by phone number specified and sets route.
Show Nearby <POI Category>	Searches for a POI near current vehicle location and sets route.
Store Location	Stores a current location.

NAV - Map

Guidance Voice	Turns on voice guidance.
Guidance Voice Repeat	Repeats voice guidance once.
Show Current Location	Displays current location map screen.
Landmark Icons	Displays all landmark icons.
Landmark Icons <POI Category>	Displays landmark icons of specified POIs.
Planview Map	Displays map in Plan View.
Birdview Map	Displays map in Birdview.
Planview Split Map	Displays map in Split (Plan View).
Birdview Split Map	Displays map in Split (BirdView).
North Up	Sets orientation of map to North Up.
Heading Up	Sets orientation of map to Heading Up.
Zoom In	Zooms map in.
Zoom Out	Zooms map out.
<1, 2, 5, 8, 32, 400> miles Scale	Displays map in specified scale (1, 2, 5, 8, 32, or 400 miles).
<1/8, 1/4, 1/2> miles Scale	Displays map in specified scale (1/8, 1/4 or 1/2 mile).
<150, 300> feet Scale	Displays map in specified scale (150 or 300 feet).
<75, 150> feet Building Scale	Displays map in specified scale (75 or 150 feet).

NAV - Route

Fastest Route	Sets route search condition to Fastest Route.
Minimize Freeway	Sets route search condition to Minimize Freeway.
Shortest Route	Sets route search condition to Shortest Route.
Cancel Route	Cancels route setting.
Detour	Calculates a detour.
Route Information	Displays route information.
Recalculate	Recalculates a route.

Phone

Phone Redial	Redials phone number last dialed.
Phone Dial	Dials phone number given in command.
Phone Dial <Phone Number>	Dials phone number given in command.
Phonebook	Shows first page of "Phonebook" list.
Phonebook <Voicetag>	Dials phone number registered in specified "voicetag".
Outgoing Calls	Shows outgoing call history (1 to 5).
Incoming Calls	Shows incoming call history (1 to 5).
Phone Select	Selects anor cellular phone registered in system.
Play Phonebook	Outputs "Voicetags" registered in system.
Play Address Book	Speaks voicetags stored in Address Book.

Utility Controls

Help	Displays command list.
Vehicle Fuel Economy	Displays Fuel Economy screen.
Maintenance	Displays Maintenance screen.
Status	Displays Status screen.

Climate Control

Climate Control	Turns climate control system on and operates it in AUTO mode.
Climate Control OFF	Turns climate control system off.
Temperature <60 - 90>	Sets climate control temperature to specified value.
Driver Temperature <60 - 90>	Sets driver's side temperature to specified value.
Passenger Temperature <60 - 90>	Sets passenger's side temperature to specified value.